



ECO60 Ultra-Slim Speaker Template

Cut Hole 5.9"

Note: Do Not Allow Silicone to Squeeze & Make Contact with Rear of Speaker Cone

6.5 inch

Installation

- 1) Find a flat location for speaker installation
- 2) Use template for approximate spacing
- 3) Cut 4.5" hole
- 4) Position speaker & mark for screw holes
- 5) Drill 1/8" screw holes
- 6) Connect (+) speaker wire to large tab, (-) speaker wire to small tab.
- 7) Apply non-caustic RTV sealant or RV putty to rear of speaker to create seal.
- 8) Position U-clip over screw holes.
- 9) Secure speakers with provided stainless steel screws



Warranty Policy
 PQN products are warranted to be free of manufactured defects for a period of one (1) year from date of purchase to original buyer.